

Discussion 13: I/O, ECC/Parity, RAID

I/O

1. Fill this table of polling and interrupts.

Operation	Definition	Pro/Good for	Con
Polling	Forces the hardware to wait on ready bit (alternatively, if timing of device is known – the ready bit can be polled at the frequency of the device). It basically means manually checking the ready bit regularly.	PRO: -easy to write -poll handler does not have excessively high overhead -deterministic -doesn't require additional hardware Good for: -Mouse, keyboard	Infeasible on hardware with fast transfer rates that is actually rarely ready (e.g. Ethernet card receiver)
Interrupts	Hardware fires an "exception" when it becomes ready. CPU changes \$PC to execute code in the interrupt handler when this occurs.	PRO: -Necessary for fast devices that are rarely ready. Good for: Fast devices - Hard drives, Network cards	-nondeterministic when interrupt occurs -interrupt handler has some overhead (saves all registers), meaning polling can actually be faster for slow, often ready devices such as mice

2. Memory Mapped I/O

Certain memory addresses correspond to registers in I/O devices and not normal memory.

0xFFFF0000 – Receiver Control:

Lowest two bits are interrupt enable bit and ready bit.

0xFFFF0004 – Receiver Data:

Received data stored at lowest byte.

0xFFFF0008 – Transmitter Control

Lowest two bits are interrupt enable bit and ready bit.

0xFFFF000C – Transmitter Data

Transmitted data stored at lowest byte.

Write MIPS code to read a byte from the receiver and immediately send it to the transmitter.

```

    lui $t0 0xffff
receive_wait: #poll on ready of receiver
    lw $t1 0($t0)
    andi $t1 $t1 1
    beq $t1 $zero receive_wait
    lb $t2 4($t0) #load data

    transmit_wait: #poll on ready of transmitter
    lw $t1 8($t0)
    andi $t1 $t1 1
    beq $t1 $zero transmit_wait
    #write to transmitter
    sb $t2 12($t0)
  
```

Hamming ECC

Recall the basic structure of a Hamming code. Given bits $1, \dots, m$, the bit at position $2n$ is parity for all the bits with a 1 in position n . For example, the first bit is chosen such that the sum of all odd-numbered bits is even.

Bit	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
Data	<u>P</u> 1	<u>P</u> 2	D1	<u>P</u> 4	D2	D3	D4	<u>P</u> 8	D5	D6	D7	D8	D9	D10	D11
P1	X		X		X		X		X		X		X		X
P2		X	X			X	X			X	X			X	X
P4				X	X	X	X					X	X	X	X
P8								X	X	X	X	X	X	X	X

- How many bits do we need to add to 00112 to allow single error correction?
Parity Bits: 3
- Which locations in 00112 would parity bits be included?
Using P for parity bits: PPOP11₂
- Which bits does each parity bit cover in 00112?
Parity bit #1: 1, 3, 5, 7
Parity bit #2: 2, 3, 6, 7
Parity bit #3: 4, 5, 6, 7
- Write the completed coded representation for 00112 to enable single error correction.
1000011₂
- How can we enable an additional double error detection on top of this?
Add an additional parity bit over the entire sequence.
- Find the original bits given the following SEC Hamming Code: 01101112
Parity group 1: error
Parity group 2: okay
Parity group 4: error
Incorrect bit: $1 + 4 = 5$, change bit 5 from 1 to 0: 0110011₂
0110011₂ → 1011₂
- Find the original bits given the following SEC Hamming Code: 10010002
Parity group 1: error
Parity group 2: okay
Parity group 4: error
Incorrect bit: $1 + 4 = 5$, change bit 5 from 1 to 0: 1001100₂
1001100₂ → 0100₂
- Find the original bits given the following SEC Hamming Code: 0100110100001102
Parity group 1: okay
Parity group 2: error
Parity group 4: okay
Parity group 8: error
Incorrect bit: $2 + 8 = 10$, change bit 10 from 0 to 1: 0100110100110₂
0100110100110₂ → 01100100110₂

RAID

Fill out the following table:

	Configuration	Pro / Good for...	Con / Bad for...
RAID 0	Data disks without check information	No overhead Fast read / write	Reliability
RAID 1	Mirrored Disks: Extra copy of disks	Fast read / write Fast recovery	High overhead → Expensive
RAID 2	Hamming ECC: One check disk per parity group	Smaller overhead	Redundant check disks
RAID 3	Single check disk for error correction (Disk controllers can detect failures) Transfer units are spread over all disks in a group (bit interleaving)	Smallest check information overhead	Read all data disks for small accesses to detect errors
RAID 4	Transfer units = a sector within a single disk Errors are detected within a single transfer unit Independent reads/writes per disks	Higher throughput of small reads	Still slow small writes (A single check disk is a bottleneck)
RAID 5	Check information is distributed across all disks in a group.	Higher throughput of small writes	

Small accesses = an access to a single disk in a group