


inst.eecs.berkeley.edu/~cs61c
CS61C : Machine Structures

**Lecture 7 – Introduction to MIPS
Decisions II**

2014-09-15


**Instructor:
Miki Lustig**



EETimes article 08/07/2014

**RISC-V: An open standard for SoCs. The case for an open
ISA (Krste, Patterson, UC Berkeley).**

While the likely first beachhead for RISC-V is the IoT, our ambitious goal is grander:
Just as Linux has become the standard OS for most computing devices, we
envision RISC-V becoming the standard ISA for all computing devices.




http://www.eetimes.com/author.asp?section_id=36&doc_id=1323406&



ANGEL

- <http://riscv.org/angel/>



Review

- Memory is **byte**-addressable, but **lw** and **sw** access one **word** at a time.
- A pointer (used by **lw** and **sw**) is just a memory address, so we can add to it or subtract from it (using offset).
- A Decision allows us to decide what to execute at run-time rather than compile-time.
- C Decisions are made using **conditional statements** within **if, while, do while, for**.
- MIPS Decision making instructions are the **conditional branches: beq and bne**.
- New Instructions:

 **lw, sw, beq, bne, j**

CS61C L06 Introduction to MIPS: Data transfer and decisions II ()

Loading, Storing bytes 1/2

- In addition to word data transfers (lw, sw), MIPS has **byte** data transfers:
 - load byte: **lb**
 - store byte: **sb**
- same format as lw, sw
- E.g., **lb \$s0, 3(\$s1)**
 - contents of memory location with address = sum of “3” + contents of register *s1* is copied to the low byte position of register *s0*.



Loading, Storing bytes 2/2

- What do we do with other 24 bits in the 32 bit register?
 - **lb**: sign extends to fill upper 24 bits



- Normally don't want to sign extend chars
- MIPS instruction that doesn't sign extend when loading bytes:
 - load byte unsigned: **lbu**



Overflow in Arithmetic (1/2)

- **Reminder: Overflow occurs when there is a “mistake” in arithmetic due to the limited precision in computers.**
- **Example (4-bit unsigned numbers):**

$$\begin{array}{r} 15 \\ + 3 \\ \hline 18 \end{array}$$

$$\begin{array}{r} 1111 \\ + 0011 \\ \hline 10010 \end{array}$$

- **But we don't have room for 5-bit solution, so the solution would be 0010, which is +2, and “wrong”.**



Overflow in Arithmetic (2/2)

- Some languages detect overflow (Ada), some don't (most C implementations)
- MIPS solution is 2 kinds of arithmetic instructions:
 - These cause overflow to be detected
 - ▣ add (**add**)
 - ▣ add immediate (**addi**)
 - ▣ subtract (**sub**)
 - These do not cause overflow detection
 - ▣ add unsigned (**addu**)
 - ▣ add immediate unsigned (**addiu**)
 - ▣ subtract unsigned (**subu**)
- Compiler selects appropriate arithmetic
- MIPS C compilers produce **addu, addiu, subu**



Two “Logic” Instructions

- Here are 2 more new instructions
- Shift Left: `sll $s1,$s2,2` #s1=s2<<2
 - Store in \$s1 the value from \$s2 shifted 2 bits to the left (they fall off end), inserting 0's on right; << in C.
 - Before: `0000 0002hex`
`0000 0000 0000 0000 0000 0000 0000 0010two`
 - After: `0000 0008hex`
`0000 0000 0000 0000 0000 0000 0000 1000two`
 - What arithmetic effect does shift left have?
- Shift Right: `srl` is opposite shift; >>



Loops in C/Assembly (1/3)

- Simple loop in C; **A[]** is an array of ints

```
do { g = g + A[i];  
    i = i + j;  
} while (i != h);
```

- Rewrite this as:

```
Loop: g = g + A[i];  
      i = i + j;  
      if (i != h) goto Loop;
```

- Use this mapping:

```
g, h, i, j, &A[0]  
$s1, $s2, $s3, $s4, $s5
```



Loops in C/Assembly (2/3)

•Final compiled MIPS code:

```
Loop: sll   $t1,$s3,2      # $t1= 4*i
      addu  $t1,$t1,$s5   # $t1=addr A+4i
      lw    $t1,0($t1)   # $t1=A[i]
      addu  $s1,$s1,$t1   # g=g+A[i]
      addu  $s3,$s3,$s4   # i=i+j
      bne   $s3,$s2,Loop  # goto Loop
                        # if i!=h
```

•Original code:

```
Loop:   g = g + A[i];
        i = i + j;
        if (i != h) goto Loop;
```



Loops in C/Assembly (3/3)

- There are three types of loops in C:
 - `while`
 - `do ... while`
 - `for`
- Each can be rewritten as either of the other two, so the method used in the previous example can be applied to these loops as well.
- **Key Concept:** Though there are multiple ways of writing a loop in MIPS, the key to decision-making is conditional branch



Inequalities in MIPS (1/4)

- Until now, we've only tested equalities (`==` and `!=` in C). General programs need to test `<` and `>` as well.
- Introduce MIPS Inequality Instruction:
 - “Set on Less Than”
 - Syntax: `slt reg1, reg2, reg3`
 - Meaning: `reg1 = (reg2 < reg3);`

```
if (reg2 < reg3)
    reg1 = 1;
else reg1 = 0;
```

← Same thing...

“set” means “change to 1”,
“reset” means “change to 0”.



Inequalities in MIPS (2/4)

- How do we use this? Compile by hand:

```
if (g < h) goto Less; #g:$s0, h:$s1
```

- Answer: compiled MIPS code...

```
slt $t0,$s0,$s1 # $t0 = 1 if g<h  
bne $t0,$0,Less # goto Less  
# if $t0!=0  
# (if (g<h)) Less:
```

- Register \$0 always contains the value 0, so **bne** and **beq** often use it for comparison after an **slt** instruction.



A **slt** → **bne** pair means **if(... < ...)goto...**

Inequalities in MIPS (3/4)

- Now we can implement $<$, but how do we implement $>$, \leq and \geq ?
- We could add 3 more instructions, but:
 - MIPS goal: **Simpler is Better**
- Can we implement \leq in one or more instructions using just **slt** and **branches**?
 - What about $>$?
 - What about \geq ?



Inequalities in MIPS (4/4)

```
# a:$s0, b:$s1
slt $t0,$s0,$s1 # $t0 = 1 if a<b
beq $t0,$0,skip # skip if a >= b
    <stuff> # do if a<b
skip:
```

Two independent variations possible:

Use `slt $t0,$s1,$s0` instead of

`slt $t0,$s0,$s1`

Use `bne` instead of `beq`



Immediates in Inequalities

- There is also an immediate version of `slt` to test against constants: `slti`
 - Helpful in for loops

C `if (g >= 1) goto Loop`

M
I
P
S `Loop: . . .`
 `slti $t0,$s0,1 # $t0 = 1 if`
 `# $s0 < 1 (g < 1)`
 `beq $t0,$0,Loop # goto Loop`
 `# if $t0 == 0`
 `# (if (g >= 1))`

An `slt` → `beq` pair means `if(... ≥ ...)goto...`



What about unsigned numbers?

- Also **unsigned** inequality instructions:

sltu, sltiu

...which sets result to 1 or 0 depending on unsigned comparisons

- What is value of \$t0, \$t1?

$(\$s0 = \text{FFFF FFFA}_{\text{hex}}, \$s1 = \text{0000 FFFA}_{\text{hex}})$

slt \$t0, \$s0, \$s1

sltu \$t1, \$s0, \$s1



MIPS Signed vs. Unsigned – diff meanings!

- **MIPS terms Signed/Unsigned “overloaded”:**
 - **Do/Don't sign extend**
 - ▶ (lb, lbu)
 - **Do/Don't overflow**
 - ▶ (add, addi, sub, mult, div)
 - ▶ (addu, addiu, subu, multu, divu)
 - **Do signed/unsigned compare**
 - ▶ (slt, slti/sltu, sltiu)



Peer Instruction


```

Loop: addi $s0 $s0      # i = i - 1
      slti $t0 $s1      # $t0 = (j < 2)
      beq  $t0 $0 Loop  # goto Loop if $t0 == 0
      slt  $t0 $s1 $s0  # $t0 = (j < i)
      bne  $t0 $0 Loop  # goto Loop if $t0 != 0
  
```

(\$s0=i \$s1=j)

What C code properly fills in the blank in loop below?

```
do {i--;} while(____);
```



“And in conclusion...”

- To help the **conditional branches** make decisions concerning inequalities, we introduce: “Set on Less Than” called **slt, slti, sltu, sltiu**
- One can store and load (signed and unsigned) **bytes** as well as words with **lb, lbu**
- Unsigned add/sub **don't cause overflow**
- New MIPS Instructions:
sll, srl, lb, lbu
slt, slti, sltu, sltiu
addu, addiu, subu

