

inst.eecs.berkeley.edu/~cs61c
UC Berkeley CS61C : Machine Structures

Lecture 17
Instruction Representation III



2008-03-03

TA Matt Johnson

inst.eecs.berkeley.edu/~cs61c-tm


iPhone games!
(and general SDK) ⇒

Apple is (finally) releasing an iPhone Software Developer Kit on March 6th (?)
That means iPhone games that use both touch and accelerometer input!



CS61C L17 MIPS Instruction Format III (1)

youtube.com/watch?v=hy0ptZisr70



Spring 2008 © UCB

Review

- **MIPS Machine Language Instruction:**
32 bits representing a single instruction

R	opcode	rs	rt	rd	shamt	funct
I	opcode	rs	rt	immediate		
J	opcode	target address				

- **Branches use PC-relative addressing,**
Jumps use absolute addressing.



CS61C L17 MIPS Instruction Format III (2)

Spring 2008 © UCB

Outline

- Disassembly
- Pseudoinstructions
- “True” Assembly Language (TAL) vs. “MIPS” Assembly Language (MAL)



Decoding Machine Language

- How do we convert 1s and 0s to assembly language and to C code?
Machine language \Rightarrow assembly \Rightarrow C?
- For each 32 bits:
 1. Look at `opcode` to distinguish between R-Format, J-Format, and I-Format.
 2. Use instruction format to determine which fields exist.
 3. Write out MIPS assembly code, converting each field to name, register number/name, or decimal/hex number.
 4. Logically convert this MIPS code into valid C code. Always possible? Unique?



Decoding Example (1/7)

- Here are six machine language instructions in hexadecimal:

```
00001025hex  
0005402Ahex  
11000003hex  
00441020hex  
20A5FFFFhex  
08100001hex
```

- Let the first instruction be at address 4,194,304_{ten} (0x00400000_{hex}).
- Next step: convert hex to binary



Decoding Example (2/7)

- The six machine language instructions in binary:

```
00000000000000000001000000100101  
000000000000001010100000000101010  
00010001000000000000000000000011  
00000000010001000001000000100000  
00100000101001011111111111111111  
00001000000100000000000000000001
```

- Next step: identify opcode and format

R	0	rs	rt	rd	shamt	funct
I	1, 4-62	rs	rt	immediate		
J	2 or 3	target address				



Decoding Example (3/7)

- Select the opcode (first 6 bits) to determine the format:

Format:

R	000000	000000	000000	000100	000000	100101
R	000000	000000	001010	010000	000000	101010
I	000100	010000	000000	000000	000000	0000011
R	000000	000100	001000	000100	000000	100000
I	001000	001010	001010	111111	111111	111111
J	000010	000000	100000	000000	000000	0000001

- Look at opcode:
0 means R-Format,
2 or 3 mean J-Format,
otherwise I-Format.



- Next step: separation of fields

Decoding Example (4/7)

- Fields separated based on format/opcode:

Format:

R	0	0	0	2	0	37
R	0	0	5	8	0	42
I	4	8	0	+3		
R	0	2	4	2	0	32
I	8	5	5	-1		
J	2	1,048,577				

- Next step: translate (“disassemble”) to MIPS assembly instructions



Decoding Example (5/7)

- MIPS Assembly (Part 1):

Address:	Assembly instructions:
0x00400000	or \$2,\$0,\$0
0x00400004	slt \$8,\$0,\$5
0x00400008	beq \$8,\$0,3
0x0040000c	add \$2,\$2,\$4
0x00400010	addi \$5,\$5,-1
0x00400014	j 0x100001

- Better solution: translate to more meaningful MIPS instructions (fix the branch/jump and add labels, registers)



Decoding Example (6/7)

- MIPS Assembly (Part 2):

```
Loop:    or    $v0,$0,$0
         slt  $t0,$0,$a1
         beq  $t0,$0,Exit
         add  $v0,$v0,$a0
         addi $a1,$a1,-1
         j    Loop
Exit:
```

- Next step: translate to C code (must be creative!)



Decoding Example (7/7)

Before Hex: • After C code (Mapping below)

```
00001025hex      $v0: product
0005402Ahex      $a0: multiplicand
11000003hex      $a1: multiplier
00441020hex      product = 0;
20A5FFFFhex      while (multiplier > 0) {
08100001hex      product += multiplicand;
                    multiplier -= 1;
                    }
```

```
or    $v0,$0,$0
Loop: slt  $t0,$0,$a1
      beq  $t0,$0,Exit
      add  $v0,$v0,$a0
      addi $a1,$a1,-1
      j    Loop
```

Exit:

**Demonstrated Big 61C
Idea: Instructions are
just numbers, code is
treated like data**

Spring 2008 © UCB

Administrivia

- **Midterm is next week! Day and location are still TBA**
 - Old midterms online (link at top of page)
 - Lectures and reading materials fair game
 - Fix green sheet errors (if old book)
- **Review session also TBA**
- **Project 2 is due March 5 at 11:59PM**
 - That's Wednesday!
 - There was a file update. See spec page.



Review from before: `lui`

- So how does `lui` help us?

- Example:

```
addi    $t0,$t0, 0xABABCD
```

becomes:

```
lui     $at, 0xABAB
ori     $at, $at, 0xCDCD
add     $t0,$t0,$at
```

- Now each I-format instruction has only a 16-bit immediate.

- Wouldn't it be nice if the assembler would do this for us automatically?

- If number too big, then just automatically replace `addi` with `lui`, `ori`, `add`



True Assembly Language (1/3)

- **Pseudoinstruction**: A MIPS instruction that doesn't turn directly into a machine language instruction, but into other MIPS instructions

- What happens with pseudo-instructions?

- They're broken up by the assembler into several "real" MIPS instructions.

- Some examples follow



Example Pseudoinstructions

- **Register Move**

```
move reg2, reg1
```

Expands to:

```
add reg2, $zero, reg1
```

- **Load Immediate**

```
li reg, value
```

If value fits in 16 bits:

```
addi reg, $zero, value
```

else:

```
lui reg, upper 16 bits of value
```

```
ori reg, $zero, lower 16 bits
```



Example Pseudoinstructions

- **Load Address: How do we get the address of an instruction or global variable into a register?**

```
la reg, label
```

Again if value fits in 16 bits:

```
addi reg, $zero, label_value
```

else:

```
lui reg, upper 16 bits of value
```

```
ori reg, $zero, lower 16 bits
```



True Assembly Language (2/3)

- **Problem:**

- When breaking up a pseudo-instruction, the assembler may need to use an extra register
- If it uses any regular register, it'll overwrite whatever the program has put into it.

- **Solution:**

- Reserve a register (\$1, called `$at` for “assembler temporary”) that assembler will use to break up pseudo-instructions.
- Since the assembler may use this at any time, it's not safe to code with it.



Example Pseudoinstructions

- **Rotate Right Instruction**

```
ror    reg, value
```




Expands to:

```
srl    $at, reg, value
```



```
sll    reg, reg, 32-value
```



```
or     reg, reg, $at
```



- **“No Operation” instruction**

```
nop
```

Expands to instruction = 0_{ten} ,

```
sll    $0, $0, 0
```



Example Pseudoinstructions

- **Wrong operation for operand**

`addu reg,reg,value # should be addiu`

If value fits in 16 bits, `addu` is changed to:

`addiu reg,reg,value`

else:

`lui $at,upper 16 bits of value`

`ori $at,$at,lower 16 bits`

`addu reg,reg,$at`

- **How do we avoid confusion about whether we are talking about MIPS assembler with or without pseudoinstructions?**



True Assembly Language (3/3)

- **MAL (MIPS Assembly Language):** the set of instructions that a programmer may use to code in MIPS; this **includes** pseudoinstructions
- **TAL (True Assembly Language):** set of instructions that can actually get translated into a single machine language instruction (32-bit binary string)
- **A program must be converted from MAL into TAL before translation into 1s & 0s.**



Questions on Pseudoinstructions

- **Question:**

- How does MIPS assembler / SPIM recognize pseudo-instructions?

- **Answer:**

- It looks for officially defined pseudo-instructions, such as **ror** and **move**
- It looks for special cases where the operand is incorrect for the operation and tries to handle it gracefully



Rewrite TAL as MAL

- **TAL:**

```
Loop:   or      $v0,$0,$0
        slt    $t0,$0,$a1
        beq   $t0,$0,Exit
        add   $v0,$v0,$a0
        addi  $a1,$a1,-1
        j     Loop
Exit:
```

- **This time convert to MAL**

- **It's OK for this exercise to make up MAL instructions**



Rewrite TAL as MAL (Answer)

• **TAL:**

```
Loop:   or    $v0,$0,$0
        slt  $t0,$0,$a1
        beq  $t0,$0,Exit
        add  $v0,$v0,$a0
        addi $a1,$a1,-1
        j    Loop
Exit:
```

• **MAL:**

```
Loop:   li    $v0,0
        ble  $a1,$zero,Exit
        add  $v0,$v0,$a0
        sub  $a1,$a1,1
        j    Loop
Exit:
```



Peer Instruction

• Which of the instructions below are **MAL** and which are TAL?

- i. `addi $t0, $t1, 40000`
- ii. `beq $s0, 10, Exit`
- iii. `sub $t0, $t1, 1`

	ABC
1:	MMM
2:	MMT
3:	MTM
4:	MTT
5:	TMM
6:	TMT
7:	TTM
8:	TTT



Peer Instruction Answer

- Which of the instructions below are **MAL** and which are TAL?

i. `addi $t0, $t1, 40000` $40,000 > +32,767 \Rightarrow \text{lui, ori}$

ii. `beq $s0, 10, Exit` **Beq: both must be registers**

iii. `sub $t0, $t1, 1` **Exit: if $> 2^{15}$, then MAL**
sub: both must be registers;
even if it was subi,
there is no subi in TAL;
generates `addi $t0, $t1, -1`

	ABC
1:	MMM
2:	MMT
3:	MTM
4:	MTT
5:	TMM
6:	TMT
7:	TTM
8:	TTT



In Conclusion

- Disassembly is simple and starts by decoding opcode field.
 - Be creative, efficient when authoring C
- Assembler expands real instruction set (TAL) with pseudoinstructions (MAL)
 - Only TAL can be converted to raw binary
 - Assembler's job to do conversion
 - Assembler uses reserved register `$at`
 - MAL makes it much easier to write MIPS

