EECS 16A Imaging 2

TA, ASE, ASE, ASE

Agenda

- Quick overview + review
- Images as matrices and vectors
- Pixel-by-pixel scanning
- Reconstructing scans as images
- Lab-specific simulation directions

Last Week: Imaging 1

• Built our very first circuit! • What did this circuit do?

Circuit Diagram

Breadboard Diagram



Today's Lab: Single Pixel Scanning

- Circuit from last week measures **light** intensity
- Simulated projector illuminates image in a controlled way
- Python programming to reconstruct image

Why?

• Imaging 1:

- Finding a link between physical quantities and voltage is powerful
- If you can digitize it, you can do anything (IOT devices, internet, code, processing)

Imaging 2:

- What measurements are good measurements?
 - Remember Kody and Nara from Dis2B

Kody and Nara

2. Finding The Bright Cave

Nara the one-handed druid and Kody the one-handed ranger find themselves in dire straits. Before them is a cliff with four cave entrances arranged in a square: two upper caves and two lower caves. Each entrance emits a certain amount of light, and the two wish to find exactly the amount of light coming from each cave. Here's the catch: after contracting a particularly potent strain of ghoul fever, our intrepid heroes are only able to see the total intensity of light before them (so their eyes operate like a single-pixel camera). Kody and Nara are capable adventurers, but they don't know any linear algebra – and they need your help.

Kody proposes an imaging strategy where he uses his hand to completely block the light from two caves at a time. He is able to take measurements using the following four masks (black means the light is blocked from that cave):



Measurement 1 Measurement 2 Measurement 3 Measurement 4

Figure 1: Four image masks.

- (a) Let x be the four-element vector that represents the magnitude of light emanating from the four cave entrances. Write a matrix K that performs the masking process in Figure 1 on the vector x, such that K x is the result of the four measurements.
- (b) Does Kody's set of masks give us a unique solution for all four caves' light intensities? Why or why not?
- (c) Nara, in her infinite wisdom, places her one hand diagonally across the entrances, covering two of the cave entrances. However, her hand is not wide enough, letting in 50% of the light from the caves covered and 100% of the light from the caves not covered. The following diagram shows the percentage of light let through from each cave:

EECS 16A, Fall 2018, Discussion 1B, Last Updated: 2018-08-29 20:39

Illuminating the Big Picture

• Linear dependence

- When can you recover your image?
- Does it matter what mask matrix you pick?
- Does it matter how you cover the pixels?

• Invertibility

- When can you solve Ax = b?
- How does this relate to our system?
- How does this affect the way we pick our masking matrix?



Seiya:





Nick:





- What are the unknowns in our system?
- Want to do an experiment to get information about these unknowns
- We can do a lot of interesting processing on vectors, but we need to convert the image into one first
 - In lecture and discussion, you have seen how to turn an image into a vector. How?



[0]	[1]
[2]	[3]
[4]	[5]

















[5]









Masked image



Image



Masked image

Image



Masked image



Image

Poll Time!

What would you expect the dimensions of a vector representing a 2x3 image to be?

- A. 2x3
- B. 3x2
- C. 6x1
- D. 5x1

To read all the pixels of a 4x4 image, how many pixel-by-pixel scans do we need to do?

- A. 4
- B. 8
- C. 16
- D. 32

Poll Time!

What would you expect the dimensions of a vector representing a 2x3 image to be?

- A. 2x3
- B. 3x2
- C. 6x1
- D. 5x1

To read all the pixels of a 4x4 image, how many pixel-by-pixel scans do we need to do?

- A. 4
- B. 8
- C. 16
- D. 32

Representing our Masks in Python



Representing our Masks in Python



Turning the Masks Into Vectors



Turning the Masks Into Vectors



1,	0,	0,	0,	0
0,	0,	0,	0,	0
0,	0,	0,	0,	0
0,	0,	0,	0,	0
0,	0,	0,	0,	0

mask0





	0,	1,	0,	0,	0
	0,	0,	0,	0,	0
mask1	0,	0,	0,	0,	0
maski	0,	0,	0,	0,	0
	0,	0,	0,	0,	0

1 0 0 0 0 0 0



1	0	0	0	0	0	0	0	
---	---	---	---	---	---	---	---	--



1	0	0	0	0	0	0	0	
0	1	0	0	0	0	0	0	
0	0	1	0	0	0	0	0	

1	0	0	0	0	0	0	0	
0	1	0	0	0	0	0	0	
0	0	1	0	0	0	0	0	
0	0	0	1	0	0	0	0	

	1	0	0	0	0	0	0	0	
	0	1	0	0	0	0	0	0	
	0	0	1	0	0	0	0	0	
	0	0	0	1	0	0	0	0	
,	0	0	0	0	1	0	0	0	
	0	0	0	0	0	1	0	0	
	0	0	0	0	0	0	1	0	

H =

Measuring a Pixel is Matrix-Vector Multiplication

1	0	0	0	0	0	0	0				
0	1	0	0	0	0	0	0				
0	0	1	0	0	0	0	0				
0	0	0	1	0	0	0	0				
0	0	0	0	1	0	0	0				
0	0	0	0	0	1	0	0				
0	0	0	0	0	0	1	0				

Masking Matrix H

Unknown, vectorized image, **∤**

i_n

i,

i₂

İ3

Recorded Sensor readings, \vec{S}

' s_n

S₁

S₂

S3

Measuring a Pixel is Matrix-Vector Multiplication

 $\vec{s} = H\vec{\iota}$

- We know H and we have the sensor readings, how do we get the image?
- How do we solve this?
- When can we solve this?
 Conditions on H

Poll Time!

Select all of the following that must be true for the image vector i to be recoverable from the sensor vector s.

- 1. H must be invertible
- 2. H must have linearly independent rows
- 3. H must be a square matrix
- 4. H must be the identity matrix

Poll Time!

Select all of the following that must be true for the image vector i to be recoverable from the sensor vector s.

- 1. H must be invertible
- 2. H must have linearly independent rows
- 3. H must be a square matrix¹
- 4. H must be the identity matrix

¹A tall matrix with redundant equations could be made to work, but noise in the system might cause the equations to become inconsistent (More in Imaging 3)

	1	0	0	0	0	0	0	0	
	0	1	0	0	0	0	0	0	
	0	0	1	0	0	0	0	0	
	0	0	0	1	0	0	0	0	
	0	0	0	0	1	0	0	0	
	0	0	0	0	0	1	0	0	
	0	0	0	0	0	0	1	0	
ſ									

H =

1	0	0	0	0	0	0	0	
0	1	0	0	0	0	0	0	
0	0	1	0	0	0	0	0	
0	0	0	1	0	0	0	0	
0	0	0	0	1	0	0	0	
0	0	0	0	0	1	0	0	
0	0	0	0	0	0	1	0	

H =





	_									7	
	1	0	0	0	0	0	0	0)	
	0	1	0	0	0	0	0	0		5	
	0	0	1	0	0	0	0	0)	
ı	0	0	0	1	0	0	0	0	 Γ	י ה	_
=	0	0	0	0	1	0	0	0		<u>′</u>	
	0	0	0	0	0	1	0	0			
	0	0	0	0	0	0	1	0			
						_					

	0,	1,	0,	0,	0
	0,	0,	0,	0,	0
	0,	0,	0,	0,	0
	0,	0,	0,	0,	0
	0,	0,	0,	0,	0

0



What Makes a Mask Good?

- Linearly independent columns -> Invertible
 - Can't get a solution without this
 - There is a unique solution
- What would be a bad mask?
- Food for thought: Are all invertible matrices equally as good?
 - Find out in Imaging 3 next week

Cumulative Scanning



In-Person: Setup



1

In-Person: Sample Setup Images





In-Person: Setup (cont.)

- 1. Draw a "simple" image
- 2. Project masks (rows of H) onto it in a dark environment
- 3. Measure ambient light sensor reading s
- 4. Multiply by H inverse to find i (= H⁻¹.s)

In-Person: Tips for a Good Image

- READ CLOSELY. There are many small directions that help you get a good setup
- Focus projector using dial on the side
- Close the box firmly & scan under dark conditions

Remote: Setup

- 1. Upload ("simple") image of an object (or use default)
- 2. Shrink your image (preferably 32x32)
- 3. 'Project' masks (rows of H) onto it and "measure" *s* using matrix multiplication
- 4. Multiply by H inverse to find *i* (= H⁻¹s)



Poll Time

Select all of the following that describe the relationship between H (the masking matrix), s (the sensor vector), and i (the image vector)?

- 1. Hs = i
- 2. Hi = s
- 3. $H^{-1}i = s$
- 4. $H^{-1}s = i$
- 5. i * s = H

Poll Time

Select all of the following that describe the relationship between H (the masking matrix), s (the sensor vector), and i (the image vector)?

- 1. Hs = i
- 2. Hi = s
- 3. $H^{-1}i = s$
- 4. $H^{-1}s = i$
- 5. i * s = H

In-Person: Opening the Lab Notebook

- Click on the "In-Person Lab Link" and download the zip file
- Unzip/extract the file: Right click -> Extract all
- Open the unzipped/extracted folder
- Right click -> Git Bash here
- Type "jupyter notebook" into the terminal and hit Enter

Important Notes (In-Person)



- You should have your kit from last week
- Equipment in cardboard box:
 - Put everything back before you leave!
 - Including Projector's Power Cable
- Make sure you are using the correct COM port
 - Not COM1, and not the debugger
- Please **GENTLY** plug in projector power jack into the **correct** port
- No signal when testing the oscilloscope on the previous circuit?
 Onplug P6.0 from MSP and debug if necessary
- Do not remove sharpies and tape from the desk
- If something isn't working, worst case, close everything and turn it back on (works 9/10 times)

Debugging (In-Person)



- 1. Make sure wires/resistors/light sensor are not loose
- 2. Light sensor orientation: short leg goes into +ve
- 3. Check COM Port
- 4. Reupload code to launchpad after making any change in circuit
- 5. Check Baud Rate in Serial Monitor (115200)
- 6. Projector might randomly restart in the middle of the lab. Make sure brightness 0 contrast 100.
- 7. Cover box with jacket for dark scanning conditions
- 8. If you see a very bright corner in the scan, move the light sensor away from the projector

Important Notes (Remote)



- 1. Pick a simple image! Quality can be lost when resizing.
- 2. Use a short / simple imagePath name
 - a. you'll have to fill this in for some cells
 - b. default is the home directory for the lab
- 3. Before starting the simulations, open up the link (in the directions above the code cell) to the display view in a different tab & observe as the cell is running
- 4. Read simulation descriptions carefully!
 - a. you might have to manually set height & width because the defaults are 32x32
- 5. Each mask section includes ideal + noisy imaging
 - a. noisy imaging meant to simulate real projector behavior
 - b. don't worry about this for now -- more to come in Img 3
- 6. If you still have an unresolved Energia error from Imaging 1, seek help from lab staff after completing Imaging 2 (iff they are available) or look out for Energia debugging sections during the week of 10/04