






Mechanical Properties of Silicon **Crystalline silicon is a hard and brittle material that deforms elastically until it reaches its yield strength, at which point it breaks. **Tensile yield strength = 7 GPa (~1500 lb suspended from 1 mm²) **Young's Modulus near that of stainless steel **\{100\} = 130 GPa; \{110\} = 169 GPa; \{111\} = 188 GPa **Mechanical properties uniform, no intrinsic stress **Mechanical integrity up to 500°C **Good thermal conductor **Low thermal expansion coefficient **High piezoresistivity

































































Recipe-Based Suppression of "Footing" Use higher process pressure to reduce ion charging [Nozawa] \diamondsuit High operating pressure \rightarrow concentration of (-) ions increases and can neutralize (+) surface charge ♦ Issue: must introduce as a separate recipe when the etch reaches the Si-insulator interface, so must be able to very accurately predict the time needed for etching Adjust etch recipe to reduce overetching [Schmidt] \clubsuit Change C_4F_8 flow rate, pressure, etc., to enhance passivation and reduce overetching ♥ <u>Issue</u>: Difficult to simultaneously control footing in a narrow trench and prevent grass in wide trenches * Use lower frequency plasma to avoid surface charging [Morioka] $\$ Low frequency ightarrow more ions with low directionality and kinetic energy → neutralizes (-) potential barrier at trench entrance ♦ Allows e^{-'}s to reach the trench base and neutralize (+) charge \rightarrow maintain charge balance inside the trench

