

---


# EE C247B - ME C218 Introduction to MEMS Design Spring 2016

Prof. Clark T.-C. Nguyen

Dept. of Electrical Engineering & Computer Sciences  
University of California at Berkeley  
Berkeley, CA 94720

Lecture Module 4: Lithography, Etching, & Doping

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    1



---

## Lecture Outline

- Reading: Senturia, Chpt. 3; Jaeger, Chpt. 2, 4, 5
  - ↳ Lithography
  - ↳ Etching
    - Wet etching
    - Dry etching
  - ↳ Semiconductor Doping
    - Ion implantation
    - Diffusion

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    2

UC Berkeley

# Lithography

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    3

UC Berkeley

# Lithography

**Lithography**  
↳ Method for massive patterning of features on a wafer → pattern billions of devices in just a few steps

**Four Main Components (that affect resolution)**

The diagram illustrates the lithography process. At the top, a radiation source (I) emits light through a mask (II) which has a designated pattern of clear or dark fields. Below the mask is a layer of photoresist (~1 μm-thick) on a film to be patterned (e.g., poly-Si). The photoresist is generated from a layout using emulsion and chrome. The exposure system (IV) involves contact, step, and repeat, with optics being the 'real art'.

I. Radiation Source

II. Mask  
Mask (glass/quartz)

III. Photoresist  
Photoresist (~1 μm-thick)

IV. Exposure System ⇔ contact, step and repeat  
↳ optics → this is where the real art is!

Designated pattern (clear or dark field)  
emulsion    chrome

Film to be patterned (e.g., poly-Si)

Generated from layout

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    4

**Lithography (cont.)**

**The basic Process - (Positive Resist Example)**

Exposed PR → converts to another form after reaction with light  
 (e.g., (+)-resist: polymer → organic acid)

Dip or spray wafer with developer → if (+) resist, developer is often a base

Etch → PR protects film; open areas of film get etched

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    5

**Lithography (cont.)**

With each masking step usually comes a film deposition, implantation and/or etch. Thus, the complexity of a process is often measured by # masks required.

- NMOS: 4-6 masks
- Bipolar: 8-15 masks
- BICMOS: ~20 masks
- CMOS: 8-28 masks

↖ Multi-level metallization

- Comb-Drive Resonator: 3 masks
- GHz Disk: 4 masks

Now, take a closer look at the 4 components:

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    6

**I. Radiation Source**

**I. Radiation Source**

↪ Several types: optical (visible, UV, deep UV light), e-beam, X-ray, ion beam

The shorter the wavelength → Better the resolution

Today's prime choice due to cost and throughput.

Can expose billions of devices at once!

**Optical Sources:**

↪ Mercury arc lamp (mercury vapor discharge)

we have all of these in our μlab

	200	365	405	435	546 nm

↪ I-line      ↪ G-line (we have both in our μlab)

↪ For deep UV, need Excimer laser (very expensive)

↪ Glass opaque, so must use quartz mask and lens

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      7

**II. Mask**

**II. Mask** → has become one of today's biggest bottlenecks!

Electronic computer representation of layout (e.g., CIF, GDSII)

⇒ A single file contains all layers

tape → mask generator

Masks for each layer


**Mask Material:**



↪ Fused silica (glass) → inexpensive, but larger thermal expansion coeff.

↪ Quartz → expensive, but smaller thermal expansion coeff.

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      8


**III. Photoresist (optical)**



	<u>Negative</u>	<u>Positive</u>
<u>Pictorial Description:</u>		
<u>Exposed Area:</u>	remains	removed

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
9

**III. Photoresist (optical)**



	<u>Negative</u>	<u>Positive</u>
<u>Mechanism:</u>	photoactivation ↓ Polymerization (long, linked Carbon chains) ↓ Developer solvent removes unexposed PR	photoactivation ↓ Converts exposed PR to organic acid ↓ Alkaline developer (e.g., KOH) removes acid

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
10

**III. Photoresist (optical)**

**Issues:**

Negative

Polymerized PR swells in solvent → bridging problem

Exposed and polymerized

Positive

Doesn't adhere well to SiO<sub>2</sub>  
 Need primer: HMDS (hexamethyl disilazane)

PR  
SiO<sub>2</sub>  
Poor adhesion

PR HMDS  
SiO<sub>2</sub>  
Good adhesion at both HMDS interfaces

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    11

**Typical Procedure for Lithography**

**Clean Wafer**    Very important step

**Dry Wafer**    30 min. @ 120°C pre-bake

**Deposit HMDS**    (for oxide on wafer surface)

**Spin-on PR**    30-60 sec @ 1000-5000 rpm

**Soft Bake**    2 min @ 90°C  
 Improve adhesion and remove solvent from PR

**Align & Expose**    Oxygen plasma (low power ~ 50W)

**Develop** → **Descum** → **Post Bake**

Topography very important:

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    12

### IV. Exposure System/Optics

#### Contact Printing

- Mask in contact with wafer
- **Problem:** mask pattern can become damaged with each exposure → must make a new mask after x number of exposures
- 1X printing very useful for MEMS → can expose surfaces with large topography (where reduction printers cannot)

#### Proximity Printing

- Mask in very close proximity but not touching

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
13

### IV. Exposure System/Optics

#### Projection Printing

- Dominates in IC transistor fabrication
- 5X or 10X reduction typical
- Mask minimum features can be larger than the actual printed features by the focused reduction factor → less expensive mask costs
- Less susceptible to thermal variation (in the mask) than 1X printing
- Can use focusing tricks to improve yield:

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
14

UC Berkeley

## Etching

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    15

UC Berkeley

## Etching Basics

- Removal of material over designated areas of the wafer
- Two important metrics:
  1. Anisotropy
  2. Selectivity

1. Anisotropy -

a) Isotropic Etching (most wet etches)

If 100% isotropic:  $d_f = d + 2h$   
Define:  $B = d_f - d$   
If  $B = 2h \Rightarrow$  isotropic

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    16



**Etching Basics (cont.)**

UC Berkeley

b) Partially Isotropic:  $B < 2h$   
 (most dry etches, e.g., plasma etching)

**Degree of Anisotropy: (definition)**

$$A_f = 1 - \frac{B}{2h} = 0 \quad \text{if 100\% isotropic}$$

$$0 < A_f \leq 1 \quad \leftarrow \text{anisotropic}$$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    17

**Etching Basics (cont.)**

UC Berkeley

2. **Selectivity** -

Only poly-Si etched (no etching of PR or  $\text{SiO}_2$ )

Perfect selectivity

PR partially etched

$\text{SiO}_2$  partially etched after some overetch of the polysilicon

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    18

### Etching Basics (cont.)

Why overetch?

$\sqrt{2}d = 1.4d = 0.56\mu\text{m} \rightarrow$  Thicker spots due to topography!

Poly-Si  $\rightarrow$  conformal if deposited by LPCVD

Thus, must overetch at least 40%:  
 40% overetch  $\rightarrow (0.4)(0.4) = 0.16\mu\text{m}$  poly  
 = ??? oxide

Depends on the selectivity of poly-Si over the oxide

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    19

### Etching Basics (cont.)

Define selectivity of A over B:

$$S_{ab} = \frac{E.R._a}{E.R._b}$$

$\leftarrow$  Etch rate of A  
 $\leftarrow$  Etch rate of B  
 $\leftarrow$  Selectivity of A over B

e.g., wet poly etch ( $\text{HNO}_3 + \text{NH}_4 + \text{H}_2\text{O}$ )

$$S_{\text{poly}/\text{SiO}_2} = \frac{15}{1} \quad (\text{very good selectivity})$$

$S_{\text{poly}/\text{PR}}$  = Very high (but PR can still peel off after soaking for > 30 min., so beware)

e.g., polysilicon dry etch:


Regular RIE  
 (but depends on type of etcher)

$$S_{\text{poly}/\text{SiO}_2} = \frac{5-7}{1}$$

$$S_{\text{poly}/\text{PR}} = \frac{4}{1}$$

ECR: 30:1  
 Bosch: 100:1 (or better)

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    20

 **Etching Basics (cont.)**

If  $S_{poly/SiO_2} = \frac{8}{1} \Rightarrow$  **40% overetch removes**

$\frac{0.16}{8} = 20 \text{ nm of oxide!} \Rightarrow$  **This will etch all poly over the thin oxide, etch thru the 10nm of oxide, then start etching into the silicon substrate  $\rightarrow$  needless to say, this is bad!**


**with better selectivity:**

e.g.,  $S_{poly/SiO_2} = \frac{30}{1}$

**(Can attain with high density Cl plasma ECR etch!)**

**40% overetch removes  $\frac{0.16}{30} = 5.3 \text{ nm}$  (better)**

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    21

 **Wet Etching**

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    22

### Wet Etching

**Wet etching:** dip wafer into liquid solution to etch the desired film  
 ↪ Generally isotropic, thus, inadequate for defining features < 3μm-wide

**General Mechanism -**

1. Diffusion of the reactant to the film surface
2. Reaction: adsorption, reaction, desorption
3. Diffusion of reaction products from the surface

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    23

### Wet Etching (cont.)

There are many processes by which wet etching can occur  
 ↪ Could be as simple as dissolution of the film into the solvent solution  
 ↪ Usually, it involves one or more chemical reactions

- Oxidation-reduction (redox) is very common:
  - (a) Form layer of oxide
  - (b) Dissolve/react away the oxide

**Advantages:**

1. High throughput process → can etch many wafers in a single bath
2. Usually fast etch rates (compared to many dry etch processes)
3. Usually excellent selectivity to the film of interest

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    24

### Wet Etching Limitations

UC Berkeley


1. Isotropic
  - ↪ Limited to  $<3\mu\text{m}$  features
  - ↪ But this is also an advantage of wet etching, e.g., if used for undercutting for MEMS
2. Higher cost of etchants & DI water compared w/ dry etch gas expenses (in general, but not true vs. deep etchers)
3. Safety
  - ↪ Chemical handling is a hazard
4. Exhaust fumes and potential for explosion
  - ↪ Need to perform wet etches under hood
5. Resist adhesion problems
  - ↪ Need HMDS (but this isn't so bad)

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    25

### Wet Etch Limitations (cont.)

UC Berkeley

6. Incomplete wetting of the surface:



Solvent bath →    wafer    Wetted surface    Pockets where wetting hasn't occurred, yet (eventually, it will occur).    But this will lead to nonuniform etching across the wafer.

↪ For some etches (e.g., oxide etch using HF), the solution is to dip in DI water first, then into HF solution → the DI water wets the surface better

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    26

**Wet Etch Limitations (cont.)**

UC Berkeley

7. Bubble formation (as a reaction by-product)  
 ↪ If bubbles cling to the surface → get nonuniform etching

**Solution:** Agitate wafers during reaction.

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      27

**Some Common Wet Etch Chemistries**

UC Berkeley

**Wet Etching Silicon:**

**Common:**  $\text{Si} + \text{HNO}_3 + 6\text{HF} \rightarrow \text{H}_2\text{SiF}_6 + \text{HNO}_2 + \text{H}_2 + \text{H}_2\text{O}$   
 (isotropic)

(nitric acid)                      (hydrofluoric acid)

(1) forms a layer of  $\text{SiO}_2$                       (2) etches away the  $\text{SiO}_2$

Different mixture combinations yield different etch rates.

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      28

### Silicon Crystal Orientation

- Silicon has the basic diamond structure
  - ↳ Two merged FCC cells offset by  $(a/4)$  in  $x$ ,  $y$ , and  $z$  axes
  - ↳ From right:
    - # available bonds/cm<sup>2</sup>  $\langle 111 \rangle$
    - # available bonds/cm<sup>2</sup>  $\langle 110 \rangle$
    - # available bonds/cm<sup>2</sup>  $\langle 100 \rangle$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    29

### Anisotropic Wet Etching

**Anisotropic etches also available for single crystal Si:**

- ↳ Orientation-dependent etching:  $\langle 111 \rangle$ -plane more densely packed than  $\langle 100 \rangle$ -plane
  - Faster E.R. (pointing to  $\langle 100 \rangle$ )
  - Slower E.R. (pointing to  $\langle 111 \rangle$ )

...in some solvents

One such solvent: KOH + isopropyl alcohol  
 (e.g., 23.4 wt% KOH, 13.3 wt% isopropyl alcohol, 63 wt% H<sub>2</sub>O)

⇒ E.R. <sub>$\langle 100 \rangle$</sub>  = 100 × E.R. <sub>$\langle 111 \rangle$</sub>

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    30

**Anisotropic Wet Etching (cont.)**

UC Berkeley

Can get the following:

(on a <100> - wafer)

(on a <110> - wafer)  
 ⇒ Quite anisotropic!

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    31

**Wet Etching SiO<sub>2</sub>**

UC Berkeley

$$\text{SiO}_2 + 6\text{HF} \rightarrow \text{H}_2 + \text{SiF}_6 + 2\text{H}_2\text{O}$$

Generally used to clear out residual oxides from contacts

**Problem:** Contact hole is so thin that surface tensions don't allow the HF to get into the contact  
 → Generally the case for VLSI circuits

300nm

native oxide can get this just by exposing Si to air → 1-2nm-thick

**Solution:** add a surfactant (e.g., Triton X) to the BHF before the contact clear etch

1. Improves the ability of HF to wet the surface (hence, get into the contact)
2. Suppresses the formation of etch by-products, which otherwise can block further reaction if by-products get caught in the contact

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    32



## More Wet Etch Chemistries

- Wet etching silicon nitride
  - ↪ Use hot phosphoric acid: 85% phosphoric acid @ 180°C
  - ↪ Etch rate ~ 10 nm/min (quite slow)
  - ↪ **Problem:** PR lifted during such etching
  - ↪ **Solution:** use SiO<sub>2</sub> as an etch mask (E.R. ~2.5 nm/min)
    - A hassle → dry etch processes more common than wet
- Wet etching aluminum
  - ↪ Typical etch solution composition:
 

(H<sub>2</sub>PO<sub>4</sub>)
(HNO<sub>3</sub>)
(CH<sub>3</sub>COOH)
(H<sub>2</sub>O)

    - (1) Forms Al<sub>2</sub>O<sub>3</sub> (aluminum oxide)
    - (2) Dissolves the Al<sub>2</sub>O<sub>3</sub>
  - ↪ **Problem:** H<sub>2</sub> gas bubbles adhere firmly to the surface → delay the etch → need a 10-50% overetch time
  - ↪ **Solution:** mechanical agitation, periodic removal of wafers from etching solution

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
33


## Wet Etch Rates (f/ K. Williams)

The top etch rate was measured by the authors with fresh solutions, etc. The center and bottom values are the low and high etch rates observed by the authors and others in our lab under less carefully controlled conditions.

ETCHANT EQUIPMENT CONDITIONS	TARGET MATERIAL	MATERIAL															
		SC Si <100>	Poly n+	Poly unimp	Wet Ox.	Dry Ox.	LTO unimp	PSG unimp	PSG unimp	SiO <sub>2</sub> nitrid	Low-d Nitrid	Al/ 2% Si	Spot Tung	Spot Ti	Spot Ti/W	OCC 820#	Otan HfPt
Concentrated HF (49%) Wet Sink Room Temperature	Silicon oxides	-	0	-	21k	F	>14k	F	30k	140	52	42	-50	F	-	F	0
10:1 HF Wet Sink Room Temperature	Silicon oxides	-	7	0	230	230	340	15k	4700	11	3	2300	2300	11k	<70	0	0
25:1 HF Wet Sink Room Temperature	Silicon oxides	-	0	0	93	93	150	W	1500	6	1	W	0	-	-	0	0
5:3 BH3 Wet Sink Room Temperature	Silicon oxides	-	9	2	1000	1000	1200	6800	4400	9	4	1400	<20	F	1000	0	0
Phosphoric Acid (85%) Heated Bath with Reflux 160°C	Silicon nitrides	-	7	-	0.7	0.8	<1	37	34	28	19	9800	-	-	-	550	390
Silicon Etchant (126 HNO <sub>3</sub> , 60 H <sub>2</sub> O, 5 NH <sub>4</sub> F) Wet Sink Room Temperature	Silicon	1800	3100	1000	87	W	110	4000	1700	2	3	4000	130	3000	-	0	0
KOH (1 KOH : 2 H <sub>2</sub> O by weight) Heated Stirred Bath 80°C	<100> Silicon	14k	>10k	F	77	-	94	W	380	0	0	F	0	-	-	F	F
Aluminum Etchant Type A (16 H <sub>2</sub> PO <sub>4</sub> , 1 HNO <sub>3</sub> , 2 H <sub>2</sub> O) Heated Bath 90°C	Aluminum	-	<10	<9	0	0	0	-	<10	0	2	6600	-	0	-	0	0
Titanium Etchant (20 H <sub>2</sub> O : 1 H <sub>2</sub> O <sub>2</sub> : 1 HF) Wet Sink Room Temperature	Titanium	-	12	-	120	W	W	W	2100	6	4	W	0	8000	-	0	0
H <sub>2</sub> O <sub>2</sub> (30%) Wet Sink Room Temperature	Tungsten	-	0	0	0	0	0	0	0	0	0	<20	190	0	60	<2	0
Piranha (-50 H <sub>2</sub> SO <sub>4</sub> , 1 H <sub>2</sub> O <sub>2</sub> ) Heated Bath 120°C	Cleaning off metals and organics	-	0	0	0	0	0	-	0	0	0	1800	-	2400	-	F	F
Acetone Wet Sink Room Temperature	Photoresist	-	0	0	0	0	0	-	0	0	0	0	-	0	-	>4k	>30k

Notation: -=not as performed, W=not performed, but known to Work (> 100 Å/min); F=not performed, but known to be Flat (< 10 Å/min); P=some of film Peled during etch or when rinsed; A=film was visibly Attacked and irregular.  
 Each entry is for a 4-inch wafer for the measurement films and half of the wafer for single-crystal silicon and the metals.  
 Etch rates will vary with temperature and prior use of solution, area of exposure of film, other materials present (e.g., photoresist), film impurities and microstructure, etc. Some variation should be expected.

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
34




## Film Etch Chemistries

- For some popular films:

Material	Wet etchant	Etch rate [nm/min]	Dry etchant	Etch rate [nm/min]
Polysilicon	HNO <sub>3</sub> :H <sub>2</sub> O: NH <sub>4</sub> F	120-600	SF <sub>6</sub> + He	170-920
Silicon nitride	H <sub>3</sub> PO <sub>4</sub>	5	SF <sub>6</sub>	150-250
Silicon dioxide	HF	20-2000	CHF <sub>3</sub> + O <sub>2</sub>	50-150
Aluminum	H <sub>3</sub> PO <sub>4</sub> :HNO <sub>3</sub> : CH <sub>3</sub> COOH	660	Cl <sub>2</sub> + SiCl <sub>4</sub>	100-150
Photoresist	Acetone	>4000	O <sub>2</sub>	35-3500
Gold	KI	40	n/a	n/a


EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
35



## Dry Etching


EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
36

### Dry Etching



- Physical sputtering
- Plasma etching
- Reactive ion etching

} All based upon plasma processes.



(+) ions generated by inelastic collisions with energetic e<sup>-</sup>'s  
 Get avalanche effect because more e<sup>-</sup>'s come out as each ion is generated.

← Develop (-) bias

← Plasma (partially ionized gas composed of ions, e<sup>-</sup>'s, and highly reactive neutral species)

↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ ↓ E-field


← wafer

Develops (+) charge to compensate for


∴ (+) ions will be accelerated to the wafer

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
37

### Physical Sputtering (Ion Milling)



- Bombard substrate w/ energetic ions → etching via physical momentum transfer
- Give ions energy and directionality using E-fields
- Highly directional → very anisotropic



ions

plasma

PR

film

Si

Steep vertical wall

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
38

### Problems With Ion Milling

PR etched down to here

Once through the film, the etch will start barrelling through the Si

1. PR or other masking material etched at almost the same rate as the film to be etched → very poor selectivity!
2. Ejected species not inherently volatile → get redeposition → non-uniform etch → grass!

- Because of these problems, ion milling is not used often (very rare)

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    39

### Plasma Etching

- Plasma (gas glow discharge) creates reactive species that chemically react w/ the film in question
- Result: much better selectivity, but get an isotropic etch

Plasma Etching Mechanism:

1. Reactive species generated in a plasma.
2. Reactive species diffuse to the surface of material to be etched.
3. Species adsorbed on the surface.
4. Chemical reaction.
5. By-product desorbed from surface.
6. Desorbed species diffuse into the bulk of the gas

← **MOST IMPORTANT STEP!** (determines whether plasma etching is possible or not.)

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    40

**Ex: Polysilicon Etching w/  $CF_4$  and  $O_2$**

UC Berkeley

$$CF_4 \xrightarrow{\text{plasma}} CF_4^+ + CF_3^+ + CF_2^+ + CF^+ + F^+ + F^0 + CF_2^+ + \dots$$

Si

Neutral radical (highly reactive!)  
 $e^- + CF_4 \rightarrow CF_3 + F + e^-$

$SiCF_6, SiF_4$  ← both volatile ∴ dry etching is possible.

- $F^0$  is the dominant reactant → but it can't be given a direction → thus, get isotropic etch!

isotropic component →  $F^0$

PR

polySi

$F^0$

$SiF_4$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    41

**Ex: Polysilicon Etching w/  $CF_4$  and  $O_2$**

UC Berkeley

isotropic component →  $F^0$

PR


polySi

$F^0$

$SiF_4$


- **Problems:**
  1. Isotropic etching
  2. Formation of polymer because of C in  $CF_4$ 
    - ↳ **Solution:** add  $O_2$  to remove the polymer (but note that this reduces the selectivity,  $S_{\text{poly/PR}}$ )
- **Solution:**
  - ↳ Use Reactive Ion Etching (RIE)


EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    42

 **Reactive Ion Etching (RIE)**

- Use ion bombardment to aid and enhance reactive etching in a particular direction
  - ↳ **Result:** directional, anisotropic etching!
- RIE is somewhat of a misnomer
  - ↳ It's not ions that react ... rather, it's still the neutral species that dominate reaction
  - ↳ Ions just enhance reaction of these neutral radicals in a specific direction
- Two principle postulated mechanisms behind RIE
  1. Surface damage mechanism
  2. Surface inhibitor mechanism

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    43

 **RIE: Surface Damage Mechanism**



- Relatively high energy impinging ions (>50 eV) produce lattice damage at surface
- Reaction at these damaged sites is enhanced compared to reactions at undamaged areas

**Result:** E.R. at surface >> E.R. on sidewalls

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    44

**RIE: Surface Inhibitor Mechanism**

UC Berkeley

- Non-volatile polymer layers are a product of reaction
- They are removed by high energy directional ions on the horizontal surface, but not removed from sidewalls

plasma

reactive radical

PR

film

Si

no reaction

(+) ions breakup the polymer layer

get reaction

**Result: E.R. @ surface >> E.R. on sidewalls**

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    45

**Deep Reactive-Ion Etching (DRIE)**

UC Berkeley

**The Bosch process:**

- Inductively-coupled plasma
- Etch Rate: 1.5-4  $\mu\text{m}/\text{min}$
- Two main cycles in the etch:
  - ↳ **Etch cycle** (5-15 s):  $\text{SF}_6$  ( $\text{SF}_x^+$ ) etches Si
  - ↳ **Deposition cycle** (5-15 s):  $\text{C}_4\text{F}_8$  deposits fluorocarbon protective polymer  $(\text{CF}_2)_n$
- Etch mask selectivity:
  - ↳  $\text{SiO}_2 \sim 200:1$
  - ↳ Photoresist  $\sim 100:1$
- **Issue:** finite sidewall roughness
  - ↳ scalloping < 50 nm
- Sidewall angle:  $90^\circ \pm 2^\circ$

Mask


Silicon

Polymer( $n\text{CF}_2$ )


Maluf

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    46

**DRIE Issues: Etch Rate Variance**



- Etch rate is diffusion-limited and drops for narrow trenches
  - ↪ Adjust mask layout to eliminate large disparities
  - ↪ Adjust process parameters (slow down the etch rate to that governed by the slowest feature)



Trench Width ( $\mu\text{m}$ )	Aspect Ratio	Etch Rate ( $\mu\text{m}/\text{min}$ )
0	$\infty$	0.5
10	15	1.25
20	7.5	1.5
30	5.0	1.65
40	3.8	1.7
50	3.0	1.72
60	2.5	1.73
70	2.1	1.74
80	1.9	1.75

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    47

**Semiconductor Doping**

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    48



**Doping of Semiconductors**

UC Berkeley

- Semiconductors are not intrinsically conductive
- To make them conductive, replace silicon atoms in the lattice with dopant atoms that have valence bands with fewer or more e<sup>-</sup>'s than the 4 of Si
- If more e<sup>-</sup>'s, then the dopant is a donor: P, As
  - The extra e<sup>-</sup> is effectively released from the bonded atoms to join a cloud of free e<sup>-</sup>'s, free to move like e<sup>-</sup>'s in a metal

- The larger the # of donor atoms, the larger the # of free e<sup>-</sup>'s → the higher the conductivity

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    49

**Doping of Semiconductors (cont.)**

UC Berkeley

- Conductivity Equation:

$$\sigma = q\mu_n n + q\mu_p p$$

conductivity ←  $\sigma$     ←  $q$  (charge magnitude on an electron)    ←  $\mu_n$  (electron mobility)    ←  $n$  (electron density)    ←  $+$     ←  $\mu_p$  (hole mobility)    ←  $p$  (hole density)
- If fewer e<sup>-</sup>'s, then the dopant is an acceptor: B
  - Lack of an e<sup>-</sup> = hole = h<sup>+</sup>
  - When e<sup>-</sup>'s move into h<sup>+</sup>'s, the h<sup>+</sup>'s effectively move in the opposite direction → a h<sup>+</sup> is a mobile (+) charge carrier

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    50

UC Berkeley

## Ion Implantation

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    51

UC Berkeley

## Ion Implantation

- Method by which dopants can be introduced in silicon to make the silicon conductive, and for transistor devices, to form, e.g., pn-junctions, source/drain junctions, ...

**The basic process:**

Control current & time to control the dose.

Charged dopant accelerated to high energy by an E-Field (e.g., 100 keV)

Masking material (could be PR, could be oxide, etc.)

Depth determined by energy & type of dopant

Result of I/I

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    52

### Ion Implantation (cont.)

**Result of I/I**

Damage → Si layer at top becomes amorphous

B not in the lattice, so it's not electrically active.

Ion collides with atoms and interacts with e<sup>-</sup>s in the lattice → all of which slow it down and eventually stop it.

High Temperature Anneal (also, usually do a drive-in diffusion) (800-1200°C)

Now B in the lattice & electrically active! (serves as dopant)

This is a statistical process → implanted impurity profile can be approximated by a Gaussian distribution.

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    53

### Statistical Modeling of I/I

Impurity concentration →  $N(x)$

Unlucky ions

Avg. ions

Lucky ions

One std. dev. away →  $0.61N_p$

2 std. dev. away →  $0.14N_p$

3 std. dev. away →  $0.11N_p$

$R_p$  Distance into Si material,  $x$

$\Delta R_p$

$R_p \triangleq$  Projected range = avg. distance on ion trends before stopping

$\Delta R_p \triangleq$  Straggle = std. deviation characterizing the spread of the distribution.

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    54

**Analytical Modeling for I/I**

**Mathematically:**

$$N(x) = N_p \exp\left[-\frac{(x - R_p)^2}{2(\Delta R_p)^2}\right]$$

Area under the impurity distribution curve } **Implanted Dose** =  $Q = \int_0^{\infty} N(x) dx$  [ions / cm<sup>2</sup>]

For an implant completely contained within the Si:

$$Q = \sqrt{2\pi} N_p \Delta R_p$$

Assuming the peak is in the silicon: (putting it in one-sided diffusion form)

$D_I = Q$  → So we can track the dopant front during a subsequent diffusion step.

$$N(x) = \frac{D_I/2}{\sqrt{\pi(Dt)_{eff}}} \exp\left[-\frac{(x - R_p)^2}{2(\Delta R_p)^2}\right], \text{ where } (Dt)_{eff} = \frac{(\Delta R_p)^2}{2}$$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    55

**I/I Range Graphs**


•  $R_p$  is a function of the energy of the ion and atomic number of the ion and target material

• Lindhard, Scharff and Schiott (LSS) Theory:

- Assumes implantation into amorphous material, i.e., atoms of the target material are randomly positioned
- Yields the curves of Fig. 6.1 and 6.2
- For a given energy, lighter elements strike Si with higher velocity and penetrate more deeply

Figure 6.1

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    56



## Diffusion

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      58

### Diffusion in Silicon

UC Berkeley

- Movement of dopants within the silicon at high temperatures
- Three mechanisms: (in Si)

(a)

(b)

(c)

#### Substitutional Diffusion

- Impurity moves along vacancies in the lattice
- Substitutes for a Si-atom in the lattice

#### Interstitialcy Diffusion

- Impurity atom replaces a Si atom in the lattice
- Si atom displaced to an interstitial site

#### Interstitial Diffusion

- Impurity atoms jump from one interstitial site to another
- Get rapid diffusion
  - ↳ Hard to control
  - ↳ Impurity not in lattice so not electrically active

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
59

### Diffusion in Polysilicon

UC Berkeley

- In polysilicon, still get diffusion into the crystals, but get more and faster diffusion through grain boundaries
- Result: overall faster diffusion than in silicon

- In effect, larger surface area allows much faster volumetric diffusion

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
60

### Basic Process for Selective Doping

UC Berkeley

1. Introduce dopants (introduce a fixed dose  $Q$  of dopants)
  - (i) Ion implantation
  - (ii) Predeposition
2. Drive in dopants to the desired depth
  - ↳ High temperature  $> 900^\circ\text{C}$  in  $\text{N}_2$  or  $\text{N}_2/\text{O}_2$

• Result:

dopants

Drive-in

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      61

### Predeposition

UC Berkeley

- Furnace-tube system using solid, liquid, or gaseous dopant sources
- Used to introduced a controlled amount of dopants
  - ↳ Unfortunately, not very well controlled
  - ↳ Dose ( $Q$ ) range:  $10^{13} - 10^{16} \pm 20\%$
  - ↳ For ref: w/ ion implantation:  $10^{11} - 10^{16} \pm 1\%$  (larger range & more accurate)
- Example: Boron predeposition

Furnace tube

Gases →

$\text{O}_2, \text{B}_2\text{H}_6$

wafer

boat

$\text{O}_2 + \text{B}_2\text{H}_6 + \text{carrier gas}$

diborane

(Inert gas: e.g.,  $\text{N}_2$  or Ar)

Predeposition Temp:  $800-1100^\circ\text{C}$

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      62

**Ex: Boron Predeposition**

UC Berkeley

- Basic Procedure:
  - Deposit  $B_2O_3$  glass
  - B diffuses from  $B_2O_3 \rightarrow Si$

- Difficult to control dose  $Q$ , because it's heavily dependent on partial pressure of  $B_2H_6$  gas flow
  - this is difficult to control itself
  - get only 10% uniformity

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    63

**Ex: Boron Predeposition (cont.)**

UC Berkeley

For better uniformity, use solid source:

Boron/Nitride wafer  
 → 2% uniformity

**Reactions:**

$$B_2H_6 + 3O_2 \rightarrow 3H_2O + B_2O_3$$

$$Si + O_2 \rightarrow SiO_2$$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    64



**General Comments on Predeposition**

- Higher doses only:  $Q = 10^{13} - 10^{16} \text{ cm}^{-2}$  (I/I is  $10^{11} - 10^{16}$ )
- Dose not well controlled:  $\pm 20\%$  (I/I can get  $\pm 1\%$ )
- Uniformity is not good
  - ↪  $\pm 10\%$  w/ gas source
  - ↪  $\pm 2\%$  w/ solid source
- Max. conc. possible limited by solid solubility
  - ↪ Limited to  $\sim 10^{20} \text{ cm}^{-3}$
  - ↪ No limit for I/I  $\rightarrow$  you force it in here!
- For these reasons, I/I is usually the preferred method for introduction of dopants in transistor devices
- But I/I is not necessarily the best choice for MEMS
  - ↪ I/I cannot dope the underside of a suspended beam
  - ↪ I/I yields one-sided doping  $\rightarrow$  introduces unbalanced stress  $\rightarrow$  warping of structures
  - ↪ I/I can do physical damage  $\rightarrow$  problem if annealing is not permitted
- Thus, predeposition is often preferred when doping MEMS

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    65

**Diffusion Modeling**

**Modeling**  $N(x)$

$\Rightarrow$  Dopants from points of high conc. move to points of low conc. w/ flux  $J$

$\Rightarrow$  Question: What's  $N(x,t)$ ?  
 ↻ fun of time

Fick's Law of Diffusion - (1<sup>st</sup> law)

$$J(x,t) = -D \frac{\partial N(x,t)}{\partial x} \quad (1)$$

↑ flux [ $\#/\text{cm}^2 \cdot \text{s}$ ]      ↑ Diffusion Coefficient

Continuity Equation for Particle Flux

General form:  $\frac{\partial N(x,t)}{\partial t} = -\nabla \cdot \vec{J}$

↑ rate of increase of conc. w/ time      ↑ negative of the divergence of particle flux

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    66

### Diffusion Modeling (cont.)

UC Berkeley

⇒ we're interested for now in the one-dimensional form:

$$\frac{\partial N(x,t)}{\partial t} = -\frac{\partial J}{\partial x} \quad (2)$$

[ $\frac{\partial}{\partial x}$  (1) and substitute (2) in (1)] ⇒  $\frac{\partial N(x,t)}{\partial t} = D \frac{\partial^2 N(x,t)}{\partial x^2}$  [Fick's 2<sup>nd</sup> Law of Diffusion in 1-D]

Solutions: → dependent upon boundary conditions  
 ↳ use variable separation or Laplace Xform techniques

Case 1: Predeposition → constant source diffusion: surface concentration stays the same during the diffusion

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      67

### Diffusion Modeling (Predeposition)

UC Berkeley

⇒ if plotted on a linear scale, would look like this:

⇒ Boundary Condition:

(i)  $N(0,t) = N_0$   
 (ii)  $N(\infty,t) = 0$

$$N(x,t) = N_0 \left[ 1 - \frac{1}{\sqrt{\pi}} \int_0^{\frac{x}{2\sqrt{Dt}}} e^{-y^2} dy \right]$$

$N(x,t) = N_0 \operatorname{erfc}\left(\frac{x}{2\sqrt{Dt}}\right)$

⇒ again, complementary error function (read tables or graph)

Done,  $Q \triangleq$  total # of impurity atoms per unit area in the Si  
 = area under the curve

$$Q = \int_0^{\infty} N(x,t) dx \Rightarrow Q(t) = N_0 \frac{2\sqrt{Dt}}{\sqrt{\pi}} \text{ cm}^{-2}$$

$2\sqrt{Dt} \triangleq$  characteristic diffusion length

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      68

**Diffusion Modeling (Limited Source)**

UC Berkeley

Case 2: Drive-in → limited source diffusion, i.e., constant dose  $Q$

Boundary Condition:

- (i)  $N(\infty, t) = 0$
- (ii)  $\frac{\partial N(x, t)}{\partial x} \Big|_{x=0} = 0$

Why? Constant Dose:  $\int_0^{\infty} N(x, t) dx = Q \leftarrow \text{const.}$

This is equivalent to saying that there's no flux going out of the Si, i.e., and that's what this says!

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    69

**Diffusion Modeling (Limited Source)**

UC Berkeley

(iii) Usually make delta fcn. approx.:  $N(x, 0) = Q \delta(x)$


⇒ we can do this, because for sufficiently long diffusion times, no matter what the original shape of the dopant distribution, the diffused distribution will be the same

Get Gaussian Distribution:  $N(x, t) = \frac{Q}{\sqrt{\pi Dt}} \exp\left[-\left(\frac{x}{\sqrt{2Dt}}\right)^2\right]$

corresponds to a half Gaussian in this equation

When the starting conc. profile is completely contained in the Si, then  $Q = \frac{D_I}{2} = \text{half the implant dose}$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    70




## Two-Step Diffusion

---

- Two step diffusion procedure:
  - ↳ **Step 1:** predeposition (i.e., constant source diffusion)
  - ↳ **Step 2:** drive-in diffusion (i.e., limited source diffusion)
- For processes where there is both a predeposition and a drive-in diffusion, the final profile type (i.e., complementary error function or Gaussian) is determined by which has the much greater  $Dt$  product:
  - $(Dt)_{\text{predep}} \gg (Dt)_{\text{drive-in}} \Rightarrow$  impurity profile is complementary error function
  - $(Dt)_{\text{drive-in}} \gg (Dt)_{\text{predep}} \Rightarrow$  impurity profile is Gaussian (which is usually the case)

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
71




## Successive Diffusions

---

- For actual processes, the junction/diffusion formation is only one of many high temperature steps, each of which contributes to the final junction profile
- Typical overall process:
  1. Selective doping
    - ↳ Implant  $\rightarrow$  effective  $(Dt)_1 = (\Delta R_p)^2/2$  (Gaussian)
    - ↳ Drive-in/activation  $\rightarrow D_2 t_2$
  2. Other high temperature steps
    - ↳ (eg., oxidation, reflow, deposition)  $\rightarrow D_3 t_3, D_4 t_4, \dots$
    - ↳ Each has their own  $Dt$  product
  3. Then, to find the final profile, use
$$(Dt)_{\text{tot}} = \sum_i D_i t_i$$

in the Gaussian distribution expression.

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
72




## The Diffusion Coefficient

$$D = D_0 \exp\left(-\frac{E_A}{kT}\right) \quad (\text{as usual, an Arrhenius relationship})$$

**Table 4.1** Typical Diffusion Coefficient Values for a Number of Impurities.

Element	$D_0(\text{cm}^2/\text{sec})$	$E_A(\text{eV})$
B	10.5	3.69
Al	8.00	3.47
Ga	3.60	3.51
In	16.5	3.90
P	10.5	3.69
As	0.32	3.56
Sb	5.60	3.95

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
73



## Diffusion Coefficient Graphs

**Substitutional & Interstitial Diffusers**




Fig. 7.1

**Interstitial Diffusers**

↳ Note the much higher diffusion coeffs. than for substitutional




Fig. 7.2

EE C245: Introduction to MEMS Design
LecM 4
C. Nguyen
8/20/09
74

**Metallurgical Junction Depth,  $x_j$**

$x_j$  = point at which diffused impurity profile intersects the background concentration,  $N_B$

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      75

**Expressions for  $x_j$**

- Assuming a Gaussian dopant profile: (the most common case)

$$N(x_j, t) = N_o \exp\left[-\left(\frac{x_j}{2\sqrt{Dt}}\right)^2\right] = N_B \rightarrow x_j = 2\sqrt{Dt \ln\left(\frac{N_o}{N_B}\right)}$$

- For a complementary error function profile:

$$N(x_j, t) = N_o \operatorname{erfc}\left(\frac{x_j}{2\sqrt{Dt}}\right) = N_B \rightarrow x_j = 2\sqrt{Dt} \operatorname{erfc}^{-1}\left(\frac{N_B}{N_o}\right)$$

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      76

## Sheet Resistance

**UC Berkeley**

- Sheet resistance provides a simple way to determine the resistance of a given conductive trace by merely counting the number of effective squares
- Definition:**

Uniformly doped material  
 w/ resistivity  $\rho = \frac{1}{\sigma}$

$\sigma = \text{conductivity} = q(\mu_n n + \mu_p p)$

$$R = \frac{\rho L}{A} = \left(\frac{\rho}{t}\right) \frac{L}{w} = R_s \left(\frac{L}{w}\right)$$

ohms per square  
 $\Omega/D$

sheet resistance      # unit squares of material in the resistor

e.g.,

5 D's of material  
 $\therefore R = R_s \times 5$

- What if the trace is non-uniform? (e.g., a corner, contains a contact, etc.)

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      77

## # Squares From Non-Uniform Traces

**UC Berkeley**

<p>0.65 squares</p>	<p>Corner = 0.56 squares</p>
<p>0.14 squares</p>	<p>0.35 squares</p>

EE C245: Introduction to MEMS Design      LecM 4      C. Nguyen      8/20/09      78

### Sheet Resistance of a Diffused Junction

UC Berkeley

- For diffused layers:

Majority carrier mobility

Net impurity concentration

Effective resistivity

Sheet resistance

$$R_s = \frac{\rho}{x_j} = \left[ \int_0^{x_j} \sigma(x) dx \right]^{-1} = \left[ \int_0^{x_j} q \mu N(x) dx \right]^{-1}$$

[extrinsic material]

- This expression neglects depletion of carriers near the junction,  $x_j \rightarrow$  thus, this gives a slightly lower value of resistance than actual
- Above expression was evaluated by Irvin and is plotted in "Irvin's curves" on next few slides
  - ☞ Illuminates the dependence of  $R_s$  on  $x_j$ ,  $N_0$  (the surface concentration), and  $N_B$  (the substrate background conc.)

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    79

### Irvin's Curves (for n-type diffusion)

UC Berkeley

**Example.** p-type

**Given:**

- $N_B = 3 \times 10^{16} \text{ cm}^{-3}$
- $N_0 = 1.1 \times 10^{18} \text{ cm}^{-3}$  (n-type Gaussian)
- $x_j = 2.77 \text{ }\mu\text{m}$

Can determine these given known predep. and drive conditions

Determine the  $R_s$ .

Using Fig. 7.7:

$R_s x_j = 470 \text{ }\Omega \cdot \mu\text{m}$

$\therefore R_s = \frac{470}{2.77} = 170 \text{ }\Omega/\square$

EE C245: Introduction to MEMS Design    LecM 4    C. Nguyen    8/20/09    80



