



Lecturer SOE
Dan Garcia

`inst.eecs.berkeley.edu/~cs61c`
UCB CS61C : Machine Structures

Lecture 9 – Introduction to MIPS Data Transfer & Decisions I

Hi to Nick Carlson from
U Northern Colorado

2008-02-11

VIDEOPHILIA?

Study finds more and more people prefer to stay indoors with computers & TVs. This has been termed "*videophilia*", and has been shown to be a cause for "obesity, lack of socialization, attention disorders and poor academic performance". Take a walk, folks!

[www.sfgate.com/cgi-bin/article.cgi?
f=/c/a/2008/02/10/MNHUURU6R.DTL](http://www.sfgate.com/cgi-bin/article.cgi?f=/c/a/2008/02/10/MNHUURU6R.DTL)



Review

- In MIPS Assembly Language:
 - Registers replace variables
 - One Instruction (simple operation) per line
 - Simpler is Better, Smaller is Faster
- New Instructions:
`add, addi, sub`
- New Registers:
C Variables: `$s0 - $s7`
Temporary Variables: `$t0 - $t7`
Zero: `$zero`




Assembly Operands: Memory



- C variables map onto registers; what about large data structures like arrays?
- 1 of 5 components of a computer: **memory** contains such data structures
- But MIPS arithmetic instructions only operate on registers, never directly on memory.
- **Data transfer instructions** transfer data between registers and memory:
 - **Memory to register**
 - **Register to memory**



Anatomy: 5 components of any Computer



Registers are in the datapath of the processor; if operands are in memory, we must transfer them to the processor to operate on them, and then transfer back to memory when done.



These are "data transfer" instructions...



Data Transfer: Memory to Reg (1/4)

- To transfer a word of data, we need to specify two things:
 - **Register:** specify this by # (\$0 - \$31) or symbolic name (\$s0, ..., \$t0, ...)
 - **Memory address:** more difficult
 - Think of memory as a single one-dimensional array, so we can address it simply by supplying a pointer to a memory address.
 - Other times, we want to be able to **offset** from this pointer.
- Remember: “**Load FROM memory**”



Data Transfer: Memory to Reg (2/4)

- To specify a memory address to copy from, specify two things:
 - A register containing a pointer to memory
 - A numerical offset (in bytes)
- The desired memory address is the sum of these two values.
- Example: $8(\$t0)$
 - specifies the memory address pointed to by the value in $\$t0$, plus 8 bytes



Data Transfer: Memory to Reg (3/4)

- Load Instruction Syntax:

1 2, 3 (4)

- where

- 1) operation name

- 2) register that will receive value

- 3) numerical offset in bytes

- 4) register containing pointer to memory

- MIPS Instruction Name:

- **lw** (meaning Load Word, so 32 bits or one word are loaded at a time)



Data Transfer: Memory to Reg (4/4)



Example: `lw $t0, 12($s0)`

This instruction will take the pointer in `$s0`, add 12 bytes to it, and then load the value from the memory pointed to by this calculated sum into register `$t0`


■ Notes:

- `$s0` is called the base register
- `12` is called the offset
- offset is generally used in accessing elements of array or structure: base reg points to beginning of array or structure (note offset must be a constant known at assembly time)



Data Transfer: Reg to Memory

- Also want to store from register into memory
 - **Store instruction syntax is identical to Load's**
- MIPS Instruction Name:
sw (meaning Store Word, so 32 bits or one word is stored at a time)



- Example: **sw \$t0, 12(\$s0)**

This instruction will take the pointer in \$s0, add 12 bytes to it, and then store the value from register \$t0 into that memory address

- Remember: **“Store INTO memory”**



Pointers v. Values

- **Key Concept:** A register can hold any 32-bit value. That value can be a (signed) `int`, an `unsigned int`, a pointer (memory addr), and so on
 - E.g., If you write: `add $t2, $t1, $t0` then `$t0` and `$t1` better contain values that can be added
 - E.g., If you write: `lw $t2, 0($t0)` then `$t0` better contain a pointer
- Don't mix these up!



Addressing: Byte vs. Word

- Every word in memory has an address, similar to an index in an array
- Early computers numbered words like C numbers elements of an array:

▫ **Memory[0], Memory[1], Memory[2], ...**

Called the "address" of a word



- Computers needed to access 8-bit bytes as well as words (4 bytes/word)
- Today machines address memory as bytes, (i.e., "**Byte Addressed**") hence 32-bit (4 byte) word addresses differ by 4

• **Memory[0], Memory[4], Memory[8]**



Compilation with Memory

- What offset in `lw` to select `A[5]` in C?
- $4 \times 5 = 20$ to select `A[5]`: byte v. word
- Compile by hand using registers:

`g = h + A[5];`

- `g: $s1, h: $s2, $s3: base address of A`
- 1st transfer from memory to register:

`lw $t0, 20($s3) # $t0 gets A[5]`

- Add 20 to `$s3` to select `A[5]`, put into `$t0`
 - Next add it to `h` and place in `g`
- `add $s1, $s2, $t0 # $s1 = h+A[5]`




Notes about Memory

- **Pitfall: Forgetting that sequential word addresses in machines with byte addressing do not differ by 1.**
 - **Many an assembly language programmer has toiled over errors made by assuming that the address of the next word can be found by incrementing the address in a register by 1 instead of by the word size in bytes.**
 - **Also, remember that for both `lw` and `sw`, the sum of the base address and the offset must be a multiple of 4 (to be word aligned)**



More Notes about Memory: Alignment

- MIPS requires that all words start at byte addresses that are multiples of 4 bytes



Last hex digit
of address is:

0, 4, 8, or C_{hex}

1, 5, 9, or D_{hex}

2, 6, A, or E_{hex}

3, 7, B, or F_{hex}

- Called Alignment: objects fall on address that is multiple of their size



Role of Registers vs. Memory

- What if more variables than registers?
 - **Compiler tries to keep most frequently used variable in registers**
 - **Less common variables in memory: spilling**
- Why not keep all variables in memory?
 - **Smaller is faster:**
registers are faster than memory
 - **Registers more versatile:**
 - MIPS arithmetic instructions can read 2, operate on them, and write 1 per instruction
 - MIPS data transfer only read or write 1 operand per instruction, and no operation



Administrivia

- **Project 1 due this Sat (not Sun) @ 11:59pm**
- **Great talk: Vincent Cerf, 5-6:30pm,**
- **Faux exam tonight @ 7pm-9pm in 306 Soda**
 - **We give you an actual exam from old Qs**
 - **You take it for an hour**
 - **You hand it your neighbor**
 - **A superstar TA will walk in and take it**
- **Other administrivia?**



So Far...

- All instructions so far only manipulate data...we've built a **calculator** of sorts.
- In order to build a **computer**, we need ability to make decisions...
- C (and MIPS) provide labels to support "goto" jumps to places in code.
 - **C: Horrible style; MIPS: Necessary!**
- Heads up: pull out some papers and pens, you'll do an in-class exercise!



C Decisions: `if` Statements

- 2 kinds of `if` statements in C

```
if (condition) clause
```

```
if (condition) clause1 else clause2
```

- Rearrange 2nd `if` into following:

```
if (condition) goto L1;
```

```
clause2;
```

```
goto L2;
```

```
L1: clause1;
```

```
L2:
```

- Not as elegant as `if-else`, but same meaning



MIPS Decision Instructions

- Decision instruction in MIPS:

```
beq  register1, register2, L1
```

beq is "Branch if (registers are) equal"

Same meaning as (using C):

```
if (register1==register2) goto L1
```

- Complementary MIPS decision instruction

```
bne  register1, register2, L1
```

bne is "Branch if (registers are) not equal"

Same meaning as (using C):

```
if (register1!=register2) goto L1
```

- Called conditional branches



MIPS Goto Instruction

- In addition to conditional branches, MIPS has an unconditional branch:

j label

- Called a Jump Instruction: jump (or branch) directly to the given label without needing to satisfy any condition
- Same meaning as (using C): **goto label**
- Technically, it's the same effect as:
beq \$0, \$0, label
since it always satisfies the condition.



Compiling C `if` into MIPS (1/2)

- Compile by hand

```
if (i == j) f=g+h;  
else f=g-h;
```

- Use this mapping:


`f`: `$s0`

`g`: `$s1`

`h`: `$s2`

`i`: `$s3`


`j`: `$s4`



Compiling C `if` into MIPS (2/2)

- Compile by hand

```
if (i == j) f=g+h;  
else f=g-h;
```



- Final compiled MIPS code:

```
    beq $s3,$s4,True    # branch i==j  
    sub $s0,$s1,$s2    # f=g-h (false)  
    j   Fin            # goto Fin  
True: add $s0,$s1,$s2  # f=g+h (true)  
Fin:
```

Note: Compiler automatically creates labels to handle decisions (branches). Generally not found in HLL code.



Peer Instruction

We want to translate $*x = *y$ into MIPS

(x, y ptrs stored in: $\$s0$ $\$s1$)

A: add $\$s0$, $\$s1$, zero

B: add $\$s1$, $\$s0$, zero

C: lw $\$s0$, 0($\$s1$)

D: lw $\$s1$, 0($\$s0$)

E: lw $\$t0$, 0($\$s1$)

F: sw $\$t0$, 0($\$s0$)

G: lw $\$s0$, 0($\$t0$)

H: sw $\$s1$, 0($\$t0$)

0:	A
1:	B
2:	C
3:	D
4:	E → F
5:	E → G
6:	F → E
7:	F → H
8:	H → G
9:	G → H



“And in Conclusion...”

- Memory is **byte**-addressable, but `lw` and `sw` access one **word** at a time.
- A pointer (used by `lw` and `sw`) is just a memory address, we can add to it or subtract from it (using offset).
- A Decision allows us to decide what to execute at run-time rather than compile-time.
- C Decisions are made using **conditional statements** within `if`, `while`, `do while`, `for`.
- MIPS Decision making instructions are the **conditional branches**: `beq` and `bne`.
- New Instructions:
`lw`, `sw`, `beq`, `bne`, `j`

